


3D Pumpkin Lantern - Cricut Instructions

Materials

- **Etsy SVGs:** <https://www.etsy.com/listing/1545878971/pumpkin-lantern-svg-halloween-lantern>
 - **100% Size**
 - 2 sheets of 8.5 x 11 transparent vellum (29 lb)
 - 7 sheets of 8.5 x 11 cardstock (65 lb)
 - **85% Size**
 - 2 sheets of 8.5 x 11 transparent vellum (29 lb)
 - 5 sheets of 8.5 x 11 cardstock (65 lb)
 - **70% Size**
 - 1 sheet of 8.5 x 11 transparent vellum (29 lb)
 - 3 sheets of 8.5 x 11 cardstock (65 lb)

Setup



- Note: only one iPad can have a Bluetooth connection at a time. Go to **Settings** on the iPad and confirm **Bluetooth** is off until you're ready to cut your design.
- When prompted, click Open Cricut Design Space
- Click on green + circle to open a new project



- Click **Projects** then **Pumpkin Paper Lantern, Customize**. The cuts made with vellum paper will need to be a different color in Cricut Design Space so that the machine will not cut them all at the same time.



Customize

- Designs can be left as they are or you can adjust the size.
- To create different sizes, highlight all the layers in the layers panel and click **Align** then **Center** to stack all pieces on top of each other.
- Grab one of the corner squares and drag it outwards (larger) or inwards (smaller), this will adjust the size of all cuts. Don't adjust just one layer because it will no longer assemble together, make sure all layers are stacked.



Cutting

- Go to **settings** on the iPad, **Bluetooth** is turned **ON**
- Once back in the design, click the **green back button** at the top left corner
- Go to **menu bar** and determine from the class which machine is available to use, the choices will be Maker & Explorer





- Click **Canvas** at the top right corner to return to your project
- Click on **Make it** in the upper right corner
- The top should show, On Mat, Mirror Off, Basic Cut and Mat Size. Adjust the mat size accordingly by clicking on it.
- Click **Next**
- Set Base Material: Select **Cardstock** for the pieces cut from cardstock (frame support, base, pattern 1 and 2, frame, and leaves) and **Vellum** for the pieces cut from vellum (matte paper and matte paper 2). Search the material list to find the appropriate material type.
- Place cardstock on the machine mat
- Push the **arrows** to load the mat slightly holding the mat guiding into the Cricut
- Click the **flashing button** to cut

- When your first mat is done, click the **arrow buttons** to unload and then load the next mat. Carefully remove design from mat, there will be small pieces.

Assembly

- Create the pumpkin frame by connecting the three frame pieces at the top and bottom notches. Note that each of the frame pieces is unique. The frame piece with two notches (#2 in the pic below) is the middle piece. The piece with the notch at the top (#1 in the pic below) slides inside the middle piece and the piece with the notch at the bottom (#3 in the pic below) slides outside the middle piece.



- Insert the pumpkin base into the assembled frame, matching notches.
- Repeat the previous step for the top pumpkin base.



- Attach the leaves to the pumpkin top, again matching notches.
- Pair one patterned side (cardstock) with one vellum piece and insert into slots in top and bottom base pieces.
- Repeat this process for all 5 of the 6 side panels.



- Before you insert the 6th side panel, add the LED tea light in the center, then close up the 6th panel.

